

ALMEMO® 8590 /8690 series



ALMEMO® precision measuring instrument for measured data acquisition, with data logger function. Comprehensive range of functions for all application areas. Increased measuring accuracy, fast measuring rate 9 measuring inputs. Operates as data logger or PC interface, also with rechargeable batteries.

Technical data and functions, ALMEMO® 8590 /8690

- Increased measuring accuracy and stability
- Fast measuring rate, up to 50 measuring operations per second
With SD memory card, up to 100 mops, optional for 1 channel up to 400 mops
- 9 measuring inputs, electrically isolated
- Over 65 standard measuring ranges
- Support for ALMEMO® plugs with multi-point adjustment, special linearization, and special measuring ranges
- Option KL for independent multi-point adjustment or special linearization programmable in 30 points and management of calibration data saved in the sensor connector and the measuring instrument
- Higher measuring quality thanks to electrical isolation between measuring inputs and device power supply (device ground)
- Improved cold junction compensation with 2 sensors
- Data logger option
Internal EEPROM sufficient for 100,000 measured values (option S) configurable as linear or ring memory - or memory connector with micro SD (accessory)
- Sleep mode for long-term recording
- 2 ALMEMO® output sockets, suitable for digital interfaces, analog output, trigger input, alarm contacts, memory card
- 5 LEDs for indicating various operating states
- Key for switching on and start / stop measuring
- Complete sensor and device programming by means of AMR-Control software (included in delivery).

Technical data ALMEMO® 8590 /8690

Precision class	AA (see page 01.04)	Operation	1 key, 5 LEDs, 2 coding switches
Measuring rate	(100), 50, 10 and 2.5 mops	Internal memory (option S)	Internal EEPROM sufficient for 100,000 measured values, configurable as linear or ring memory
Measuring inputs	9 ALMEMO® input sockets	External memory (accessory)	ALMEMO® memory connector with micro SD card
Electrical isolation for analog sensors	with semiconductor relays (50 V) Additional electrical isolation between measuring inputs and power supply (device ground)	Date and time-of-day	Real-time clock, buffered with lithium battery
Additional channels	4 function channels, device-internal	Current consumption (without input and output modules)	
Outputs	2 ALMEMO® sockets, suitable for all output modules (analog / data / trigger / relay cables, memory, etc.)	Active mode	approx. 25 mA
		Sleep mode	approx. 0.05 mA

ALMEMO® 8590 /8690, accessories

Order no.

Memory connector with micro SD, including USB card reader (see chapter „General accessories“)
DC adapter cable, 10 to 30 VDC, 12 V / 1 A, electrically isolated

ZA1904SD
ZB3090UK2


ALMEMO® 8590 /8690, connecting cable

Order no.

USB data cable, electrically isolated
V24 data cable, electrically isolated
Ethernet data cable, electrically isolated
Analog output cable, -1.25 to +2.0 V, 0.1 mV / digit
Trigger and alarm cable (2 relays, 0.5 A, 50 V)
Network technology, Bluetooth modules (see chapter „Networking“)


ZA1919DKU
ZA1909DK5
ZA1945DK
ZA1601RK
ZA1006EKG

ALMEMO® 8590-9



Precision measuring instrument, 9 measuring inputs
Data logger option with internal memory or external memory connector (accessory)

ALMEMO® 8690-9A



Precision measuring instrument, 9 measuring inputs
Data logger option with internal memory or external memory connector (accessory)
Runs on rechargeable batteries, charging via the device itself

Technical data and functions

- Technical data and functions, as for ALMEMO® 8590 / 8690

Technical data

Technical data, as for ALMEMO® 8590 / 8690

Sensor power supply	Mains adapter 12 V, maximum 0.5 A
Power supply	
Mains adapter	ZB1212NA10 100 to 240 VAC to 12 VDC, 2 A, electrically isolated
DC adapter cable	ZB3090UK2 10 to 30 VDC, 1 A, electrically isolated
Housing	180 x 49 x 137 mm (LxWxH) Polystyrene (PS) Weight approx. 490 g

Technical data and functions

- Technical data and functions, as for ALMEMO® 8590 / 8690
- Runs on rechargeable batteries, high-speed charging in the device itself using mains unit, included in delivery

Technical data

Technical data, as for ALMEMO® 8590 / 8690

Rechargeable battery pack	8 rechargeable NiMH batteries, 9 to 11 V, 1600 mAh With intelligent high-speed charging (3.5 hours)
Sensor power supply	
Mains adapter	12 V, maximum 0.5 A
Runs on rechargeable batteries	9 to 11.5 V, maximum 0.5 A
Power supply	
Mains adapter	ZB1212NA10 100 to 240 VAC, to 12 VDC, 2 A
DC adapter cable	electrically isolated ZB3090-UK2 10 to 30 VDC, 12 VDC, 1 A
Housing	218 x 77 x 145 mm (LxWxH) Polystyrene (PS) Weight approx. 1.2 kg

Options

Order no.

Internal data memory sufficient for 100,000 values	OA8590S
Multi-point adjustment, special linearization, management of calibration data	OA8590KL
Temperature ranges for 8 refrigerants (see 10.08)	SB0000R2
Measuring rate for 1 measuring channel, 400 mops (SD card required)	SA0000Q4
DIN rail mounting	OA2290HS

Standard delivery

Order no.

Mains plug assembly ZB1212NA10, operating instructions, manufacturer's test certificate	
Precision measuring instrument ALMEMO® 8590-9 for measured data acquisition	MA85909

Options

Order no.

Internal data memory sufficient for 100,000 values	OA8590S
Multi-point adjustment, special linearization, management of calibration data	OA8590KL
Temperature ranges for 8 refrigerants (see 10.08)	SB0000R2
Measuring rate for 1 measuring channel, 400 mops (SD card required)	SA0000Q4
DIN rail mounting	OA2290HS

Standard delivery

Order no.

Rechargeable batteries, mains plug assembly ZB1212NA10, Operating instructions, manufacturer's test certificate	
Precision measuring instrument ALMEMO® 8690-9A for measured data acquisition	MA86909A

DAkkS or works calibration KE90xx, electrical, for measuring instrument (see chapter „Calibration certificates“).
 DAkkS calibration meets all the requirements regarding test resources laid down in DIN EN ISO/IEC 17025.